


BS-370 AUX function and Handheld Scanner Connection SOP

- Connect handheld scanner on BS-370 AUX port.
- Connect BS-370 PORT1 on PC.
- Connect Power on BS-370


BS-370 Enable AUX function

Scan the following code to open AUX port.


Open programming mode



Turn AUX port ON



Close programming mode



Handheld Scanner Setting to connect with BS-370

Scanner the following codes to setup handheld scanner.

Start Configuration



RS232 Mode



Stop bit: 2 bits

2 Bits



RTS/CTS Enable



Code ID: ON

ON



Set Code ID:

EAN-13/JAN-13



F



EAN-8/JAN-8



F



UPC-A



E



UPC-E



E



Interleave 25



I



CODE 39



M



CODABAR/NW7



N



CODE 128



K



End Configuration



Save Parameters

